

# Characteristics

## Electrical

### Power supply

Voltage range: 216.2 - 253V

Frequency: 50Hz (nom)

Phases: 1

Power: Programmer: 3VA (max)

Fuse: 1.0A slow-blow HRC  
20mm x 5mm ceramic

### Control Relays

Contact type: SPST NO volt-free  
nominal 230VAC switching  
@300mA max (contactor driving)  
@24A max (direct switching)

### Thermocouple

R,S,K & N type.

### Power Connector (ST030B)

24A Terminal block (7.62mm pitch)  
"Rising clamp" type

### Power Connectors (ST036A)

Pluggable Terminal blocks (5mm pitch)  
"Rising clamp" type

### Thermocouple Connector

Pluggable terminal block (3.5mm pitch)  
"Rising clamp" type

### Jumper Wire (ST030B only)

90mm long 2.5mm<sup>2</sup>

## Error Handling

Thermocouple failure detection

Thermocouple reversal detection

Heater failure detection

Kiln over-temperature detection

Room over-temperature detection

Firing run time hours limiter

Alarm buzzer

## Other

Keyboard lock facility + indicator

Kiln heating indicator

Program running indicator

## Weight

Instrument + wall bracket: 0.710kg

Shipping weight: 1.180kg

## Temperature

### Temperature setting

Range: 0 to 1320°C (R/S) 0 to 1200°C (K/N)

Resolution: 1°C

### Control Accuracy

P.I.D. Control

Reading accuracy: ±0.25% FSD ±1 digit

## Time

Start delay range: 00:00 to 99hr 59min

Soak time range: 00:00 to 99hr 59min

Resolution: 1 min

## Ramps

Ramp rate: 1 to 999°C/hour or full power

Ramps can be heating or cooling

## Environmental

Operating temperature range: -10°C to +55°C

Storage temperature range: -10°C to +55°C

RH: Maximum relative humidity 80% for  
temperatures up to 31°C decreasing linearly to  
50% relative humidity at 55°C.

## Enclosure

Material: ABS

Size: 120x122x58mm

Sealing: IP65

Fixings: 90x110mm (4 off)

Colour: Light Grey  
(RAL 7035)

Holster style wall mounting  
bracket



This instrument complies with  
Council Directive 89/336/EC  
(EMC) & Council Directive  
2006/95/EC (safety)

Council Directives 2002/96/EC & 2003/108/EC



The crossed out bin symbol, placed on  
this product, reminds you of the need to  
dispose of the product properly at the  
end of its life. Electrical & Electronic

Equipment should never be disposed of  
with general waste but must be separately col-  
lected for proper treatment. In this way you will  
assist in the recovery, recycling & reuse of many  
of the materials used in this product.

**STAFFORD**  
INSTRUMENTS **D**

**ST31XA Series**

# Installation Instructions

## ST31XA Series (ST312A, ST314A, ST315A & ST316A) Temperature Programmers

Stafford Instruments Ltd.  
Tel: +44(0)1785 255588  
Fax: +44(0)1785 255589

www.staffordinstruments.co.uk  
email: support@stafford-inst.co.uk



# Installation

## Safety Warnings



ISOLATE  
BEFORE  
REMOVING  
COVER

### WARNING

ISOLATE KILN & PROGRAMMER FROM ELECTRICAL SUPPLY BEFORE OPENING THIS INSTRUMENT FOR INSTALLATION, CONFIGURATION OR REPAIR PURPOSES

### IMPORTANT

Error messages are provided to detect kiln faults and so offer some protection to the kiln. For increased protection the use of a heat fuse or other independent over-temperature trip (such as the Stafford Instruments ST121) is recommended. For maximum protection an independent thermocouple, trip & heater contactor circuit should be used.

Error messages should normally be left enabled. Error messages should only be disabled as a short term measure—to diagnose kiln problems for example. Power fail recovery may need to be disabled if un-attended firing is not allowed.

Installation

## Installer Information

Installation Category: II  
Pollution Class: 2

230V ~ 50HZ 1.0A

Fuse: 1.0A Anti-surge  
20mm ceramic HRC



IP65




## EMC

To meet Electromagnetic Compatibility requirements both the thermocouple lead and the power leads should not exceed 3.0m in length.

This instrument is designed for use mainly in Domestic & Light Industrial environments where electromagnetic interference may cause a loss of accuracy of the displayed temperature reading of up to 3°C. Specified accuracy will be restored when the interference is removed.


Installation



- °C
- °C/hr
- hr.min

The PID menu is now displayed. To review or change PID settings press the **↑** or **↓** keys. **Only enter the PID menu if you know what you are doing!** To skip PID setting press the START/STOP key.


Pressing the START/STOP key causes the instrument to store the configuration data and then leave configuration mode by resetting itself without changing PID values.



- °C
- °C/hr
- hr.min

If the START/STOP key is pressed when this menu is shown then the factory default values for PID will be reloaded. The default values are P: 55°C, I: 200 seconds, D: 10 seconds.

Pressing the START/STOP key causes the instrument to reload the factory default values for PID, store the configuration data and then leave configuration mode by resetting itself.



- °C
- °C/hr
- hr.min

If the START/STOP key is pressed when this menu is shown then the menu for reviewing or changing P (the proportional band) is shown:-



- °C
- °C/hr
- hr.min

To change the proportional band use the **↑** or **↓** keys. The factory default value for the proportional band is 55°C. It can be changed in the range 1°C to 999°C. To change I (the integral time) press the START/STOP key:-



- °C
- °C/hr
- hr.min

To change the integral time use the **↑** or **↓** keys. The factory default value for the integral time is 200 seconds. It can be changed in the range 10 seconds to 999 seconds. To disable the integral term press the **↓** key when I=10 to select I=0. To change D (the derivative time) press the START/STOP key:-



- °C
- °C/hr
- hr.min

To change the derivative time use the **↑** or **↓** keys. The factory default value for the derivative time is 10 seconds. It can be changed in the range 0 seconds (disabled) to 999 seconds. To exit the configuration setting press the START/STOP key.

The instrument will now store the new PID data, store the configuration data and then leave configuration mode by resetting itself.

## Mounting

### Mounting Location

Mount the instrument on a suitable vertical surface which will not get hot. Choose a position where the instrument is not exposed to direct heat from the kiln - especially when the kiln door or lid is open.

The cable entry in the instrument base should normally be positioned downwards to guard against moisture ingress.

### Wall Mounting Bracket

This is a single part "holster" style metal bracket. The instrument can be removed from this bracket for in-hand programming if required.

### Direct Wall Mounting

If direct wall mounting is required screw the instrument back box to the wall using the 4 moulded holes on 90mm x 110mm centres.

**Note: these holes are sealed from the interior of the instrument. It is not good practice to drill further holes in the base of the instrument because this will compromise both the IP65 sealing and the double insulation.**

## Configurations

### Kiln Contactor Driving

For operating kilns with contactors fitted please refer to the wiring diagrams on pages 4,5 & 6.

### Direct Kiln Driving (option P)

For directly driving the elements of small kilns without contactors please refer to the wiring diagram on page 7.

### Options

A "P" option code written on the yellow warning label attached to the top surface of the base box shows the type of factory set base wiring:-



Standard configuration - for contactor driving. Internal link is fitted between terminals "FL" and "CO". See diagram on pages 5 & 6.



Power configuration - for direct driving of kiln elements. Internal link is fitted between terminals "L" and "K2". See diagram on page 7.

Non-standard instruments will have additional option codes.


## Wiring

### Connector

If the instrument has been pre-wired with a cable & plug ensure that the plug is compatible with the connector fitted to the kiln. The standard connector is Harting type HAN 7D or similar.

### Kiln Connections

Compatible kiln connector wiring is shown below:-




### Connector Pin List

1	Neutral to contactors	5	Mains Live supply
2	Mains Neutral supply	6	Kiln Power contactor Live
3	Thermocouple +	7	Auxiliary contactor Live
4	Thermocouple -	Earth	Earth

### Contact Suppression

The coil of each contactor **should be suppressed** with an RC suppressor. The RC suppressor must be connected directly across the coil terminals on the contactor. Suitable proprietary RC suppressors are often available from contactor manufacturers as add-on blocks. A suitable RC suppressor with insulated wire leads is available from Farnell Electronic Components as part number: 1187659 - these **are also available from Stafford Instruments Ltd.**

### HAN 7D Pinout



View on pins

At.50

°C  
 °C/hr  
 hr.min

The ambient temperature trip level is now displayed. This can be altered with the **↑** & **↓** keys in the range 30°C to 70°C or disabled (At.--). If this temperature is exceeded the controller will show Err7. Press the START/STOP key.

E1.1

°C  
 °C/hr  
 hr.min

Error 1 (heating failure) message status is now displayed. This can be altered with the **↑** & **↓** keys. E1.1 indicates that error 1 is enabled. E1.0 indicates that error 1 is disabled. Press the START/STOP key.

E4.1

°C  
 °C/hr  
 hr.min

Error 4 (contactor welded) message status is now displayed. This can be altered with the **↑** & **↓** keys. E4.1 indicates that error 4 is enabled. E4.0 indicates that error 4 is disabled. Press the START/STOP key.

E5.--

°C  
 °C/hr  
 hr.min

Error 5 (overshoot limit exceeded) message status is now displayed. This can be altered with the **↑** & **↓** keys to E5.10 (10°C), E5.20 (20°C), E5.30 (30°C), E5.40 (40°C), E5.50 (50°C) or E5.-- (disabled). Press the START/STOP key.

PF.1

°C  
 °C/hr  
 hr.min

Power failure handling status is now displayed. This can be altered with the **↑** & **↓** keys. PF.1 indicates that power failure recovery is enabled. PF.0 indicates that power failure recovery is disabled. Press the START/STOP key.

The lock-up on error facility described below is used to prevent the clearing of errors by cycling the power to the instrument - to force an engineer call-out. Errors are cleared by entering this configuration mode.

LE.0

°C  
 °C/hr  
 hr.min

Lock-up on error status is now displayed. This can be altered with the **↑** & **↓** keys. LE.1 indicates that lock-up on error is enabled. LE.0 indicates that lock-up on error is disabled. Press the START/STOP key.

## Configuring

The following installation parameters of the instrument can be configured:-

- ◆ Thermocouple type                      default: R type
- ◆ Maximum allowed kiln temperature    default: 1320°C (R/S), 1200°C (K/N)
- ◆ Kiln power rating                        default: 0.0kW
- ◆ Maximum firing time hours limit default: disabled
- ◆ Ambient (room) temperature trip:     default: 50°C
- ◆ Error 1 enabled/disabled               default: enabled
- ◆ Error 4 enabled/disabled               default: enabled
- ◆ Error 5 temperature overshoot limit:   default: disabled
- ◆ Power fail recovery enabled/disabled   default: enabled
- ◆ Lock-up on error enabled/disabled     default: disabled

To enter configuration mode power down the instrument. Press and hold down the START/STOP key while powering up the instrument. Release the START/STOP key when the thermocouple type is displayed.


**Note: in the sequence below if no key presses are detected within 15 seconds the instrument will exit configuration mode and configuration changes will not be saved.**

tC.r	○ °C	The currently configured thermocouple type letter will flash. This can be altered with the <b>↑</b> & <b>↓</b> keys to R,S,K or N type (r5Hn). Press the START/STOP key.
1320	● °C ○ °C/hr ○ hr.min	The maximum allowable kiln temperature is now displayed. This can be altered with the <b>↑</b> & <b>↓</b> keys. Press the START/STOP key.
P 0.0	○ °C ○ °C/hr ○ hr.min	The currently configured kiln power rating in kW is now displayed. This can be altered with the <b>↑</b> & <b>↓</b> keys. Press the START/STOP key.
H.---	○ °C ○ °C/hr ○ hr.min	The maximum firing hours limit is now displayed. This can be altered with the <b>↑</b> & <b>↓</b> keys in the range 10 to 999 hours or disabled (---). If this limit is exceeded the controller will show Err5. Press the START/STOP key.

## Wiring In - ST31XA (ST036A PCB)

If a pre-wired cable & plug is not fitted then the instrument can be wired to the kiln as shown below.

**Note: Identify the type of circuit board fitted before proceeding (ST036A or ST030B). Wiring details for ST030B board shown overleaf. Wiring in should only be performed by a qualified person - preferably an experienced kiln electrician.**



### Configuration


The relay contacts are volt-free. To power the contacts fit a jumper link between terminals FL (fused live) & CO (common) as shown above. A jumper link should also be fitted between terminals S1 & S2 (if a mains switch is not fitted).

### Note

The auxiliary / alarm relay (RL2) contacts close at the start of firing and open when firing is complete. The contacts also open if an error message is generated. This relay can be used to drive a secondary contactor to isolate kiln power.

## Wiring In - ST31XA (ST030B PCB)

**Wiring in should only be performed by a qualified person - preferably an experienced kiln electrician.**  
 If a pre-wired cable & plug is not fitted then the instrument can be wired to the kiln as shown below.




### Configuration

The relay contacts are volt-free. To power the contacts fit a jumper link between terminals FL (fused live) and CO (common) as shown above. A suitable 90mm long jumper wire is provided (SI part no. 020011).

### Note

The auxiliary / alarm relay (RL2) contacts close at the start of firing and open when firing is complete. The contacts also open if an error message is generated. This relay can be used to drive a secondary contactor to isolate kiln power.

## Wiring In - ST31XPA (ST030B PCB)



**Wiring of direct power switching controllers should only be performed by a kiln manufacturer or an experienced kiln electrician.**

### Configuration

The relay contacts are volt-free. To power the contacts fit a jumper link between terminals L (live) and K2 as shown above. A suitable 90mm long jumper wire is provided (SI part no. 020011).

### Note

The auxiliary alarm / safety relay (RL2) contacts close at the start of firing and open when firing is complete. The contacts also open if an error message is generated.